



INSTRUCTION SHEET

1. Fasten loop (16) to center column (17). Fasten bent arm to (21) center cloumn (17) with screws (20).
2. Open two end links of chain ,lock the loop (16) into one end link, slip wire through the chain, the other end link lock unto chain holder (15).
3. Shut electricity off. Fasten mounting strap (12) to outlet box (9) with mounting screw (13). Thread nipple (8) up into mounting strap (12) and adjust the nipple to be a suitable location. Revolve the ring (22) to chain holder (15). Using wire nuts (3) to connect lead wire (5) and supply wire (10), lock ground wire (11) and ground wire (2) in outlet box to mounting strap (12) with ground screw (4). Fasten canopy (14) to outlet box (9) with chain holder (15).
4. Put the glass shade (8) into glass ring (19). Hook the bent arm (21) into glass ring .Adjust fixture body.




INSTALLATION AND SAFETY INSTRUCTIONS

FOR YOUR SAFETY

WARNING: BE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS SHUT OFF. EITHER THE FUSE REMOVED OR THE CIRCUIT BREAKER OFF .

GENERAL

You don't need special tools to install this fixture. Be sure to follow the steps in the order given. Under no circumstances should a fixture be hung on house electrical wires, nor should a swag type fixture be installed on a ceiling which contains a radiant type heating system. Read instructions carefully. If you are unclear as to how to proceed, consult a qualified electrician.



ASSEMBLY

Carefully remove the fixture from the carton and check that all parts are included, as shown in Figure 1, 2 & 3. Be careful not to misplace any of the screws or parts which are needed to install this fixture.

STEP 1:

NOTE: CENTERPIPE [P] Assembly may be factory installed (if installed, Proceed to Step 2). Pass fixture wires through coupling [M] and thread center pipe [P] into coupling [M] until secure.


FOR CHAIN HUNG (FIG. 1)

STEP 2:

Install canopy loop (E) on canopy (G) with lockwasher (Q) and nut (B). (Note: Loop may be factory installed.)

STEP 3:

Install lock washer (Q), nipple (C) and fixture loop (J), in that order, on coupling (M).



ITEM

Fill in item number located on carton and file this sheet for future reference

VO-195

ASSEMBLY CONT.

VO-195

STEP 2: FOR FLUSH MOUNT (IF APPLICABLE) (FIG. 3)

Install nipple (C) onto coupling (M) (if applicable).

STEP 3:

Insert fixture assembly through canopy (G). Secure in place with lock washer (Q) and nut (B).

INSTALLATION

IMPORTANT: DO NOT ATTACH FIXTURE DIRECTLY TO OUTLET BOX.

STEP 1:

Thread fixture mounting screws (I) in through top of mounting bar (A) (raised side is on top, as illustrated). Run screw threads all the way down to the heads. Secure mounting bar (A) to outlet box with outlet box screws (not supplied). For flush mount proceed to step 4.

STEP 2: FOR CHAIN HUNG ONLY

Using 2 pair of pliers, open one link of chain (N) and connect it to the fixture loop (J) at the top of the fixture. Attach the other end of the chain (N) to the canopy loop (E).

BE SURE TO CLOSE ALL CHAIN LINKS COMPLETELY.

STEP 3:

Lace fixture wire up through entire chain [N] and pass through canopy loop [E]. We recommend lacing wire up through every other link of chain (N).

STEP 4:

A. Take note of the color of the wire(s) on your fixture. Identify which group your fixture wire(s) falls into and connect the wires according to the directions below:

GROUP A: CONNECT TO BLACK HOUSE WIRE	GROUP B: CONNECT TO WHITE HOUSE WIRE
BLACK	WHITE
*PARALLEL WIRE (ROUND & SMOOTH)	*PARALLEL WIRE (SQUARE & RIDGED)
WHITE OR GREY WITH TRACER	WHITE OR GREY WITHOUT TRACER
BROWN, GOLD OR BLACK WITHOUT TRACER	BROWN, GOLD OR BLACK WITH TRACER

*Note: When parallel wire is used, the tracer wire is square shaped or ridged and less tracer wire is round in shape or smooth. (Seen best when viewed from wire end.) To separate wires, grasp the ends of each wire and pull apart.

B. Take your fixture wire(s) from group A and place evenly against the black wire from the outlet box. **DO NOT** twist wires together before using wire connectors.

C. Fit a wire connector (not supplied) over the wires and screw the connector clockwise until you feel a firmness.

D. Try gently to pull the connector off the wires. If you can pull the connector off, carefully re-do steps B and C, as above and check again for a firm connection.

E. Connect the fixture wire from group B to the white wire from the outlet box in the same manner.

STEP 6:

GROUNDING INSTRUCTIONS: The green grounding screw (D) is to be inserted into the hole with two raised dimples provided on the mounting bar (A). Wrap the ground wire from the fixture (if supplied) and the ground wire from the outlet box (bare metal or green insulated wire) around the green grounding screw (D) on the mounting bar (A) if uninsulated wire is on the mounting bar (A), connect the ground wire from the fixture (if supplied) and the outlet box to it using a small wire connector (not supplied).

NOTE: Underwriters Laboratories (U.L.) does not require all fixtures to have ground wires. These fixtures still meet all U.L. specifications. The listing mark of Underwriters on the product identifies products manufactured under its listing and Follow-Up Service Programs.

NEVER CONNECT GROUND WIRE TO BLACK OR WHITE POWER SUPPLY WIRES.

FINAL ASSEMBLY

Make sure no bare wires can be seen outside wire connectors.

STEP 1:

After wires are connected, tuck them carefully inside outlet box and then raise the canopy [G] against ceiling allowing for mounting screws (I) to protrude through holes in canopy (G). Secure in place with cap nuts (F).

STEP 2:

Install candle covers (T) (if applicable).

STEP 3:

Install lamps.

CLEANING

To clean, wipe fixture body with a soft cloth. Clean glass with a mild soap. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

ORDERING PARTS

Keep this sheet for future reference, and in case you need to order replacement parts. All parts for this fixture can be ordered from place of purchase. Be sure to use exact wording from illustration when ordering parts.

REPLACING GLASS

To replace glass, bend upper and lower tabs in corners of glass to be replaced. Install glass up through bottom of fixture. Bend tabs back as before.

"USE HOOK TO SUPPORT CHAIN, NOT THE ELECTRICAL CORD", "LE CROCHET DOIT SUPPORTER LA CHAÎNE ET NON LE CORDON ÉLECTRIQUE".

PENETRATING LINE DRAWING

Note:

Ground wire (3) and supply

wires (4) should put

through the central tube (2)



and swivel (1),

and relative position should

correspond with the cut

drawing to prevent from

scratching the supply wires.



VO-198